

LOCATE TIE DOWN FORWARD SIDE OF SPAR
AT #4 RIB LOCATION FROM TIP OF WING.

