



Place mark on outer skin 5 15/32" AFT of rear / lower engine mount bracket bolt.

Align carefully 1/10" error aligning the string to mark equals about 1 inch vertical change at the elevator hinge.

TCD method of leveling Culver Cadet LCA & LFA